Congratulations on your purchase of a high-quality Insignia product. Your NS-IPSD4 represents the state of the art in MP3 speaker docks and is designed for reliable and trouble-free performance.

Package contents

- Speaker dock
- iPod docking brackets
- Remote control with battery
- *User Guide*
- *Quick Setup Guide*

Features

- Certified iPod connector installed for iPod dock
- Recharge circuit for iPod/mini/nano/ photo/video
- Includes docking brackets to fit iPod players
- Controls a connected iPod
- Digital volume control
- 3.5 mm type Aux-In jack for shuffle and other audio players
- 3.5 mm type Aux-Out jack
- See-through LCD display
- Built-in AC line cord
- Battery backup for clock (2 x AAA not included)
- Full-feature remote control

Top view



#	Description
1	Power/play/pause button
2	Next/+ and Prev/- buttons
3	Volume +/- button
4	CLK Set button
5	EQ (equalizer) button
6	Docking station

Bottom view



#	Description
7	Backup battery compartment
8	LCD display
9	**AUX Out** port
10	**AUX In** port

Setting up your speaker dock

To connect the power to your speaker dock:

- Plug the power cord into a 120 V/60 Hz AC wall outlet.



To install the backup batteries:

1. Open the backup battery compartment on the bottom of your speaker dock.



2. Insert two AAA batteries (not included), noting the positive (+) and negative (-) markings in the compartment.
3. Replace the battery compartment cover.

Setting the clock

1. Press and hold **CLK SET** until the display flashes.
2. Press **NEXT/+** ►►I or **PREV/-** I◄◄ to select the 12 or 24 hour clock, then press **CLK SET**.
3. Press **NEXT/+** ►►I or **PREV/-** I◄◄ to adjust the hour, then press **CLK SET**.
4. Press **NEXT/+** ►►I or **PREV/-** I◄◄ to adjust the minute, then press **CLK SET** to exit.

Docking an iPod with your speaker dock

1. Locate the numbered iPod bracket that fits your iPod.



2. Snap the bracket into place over the iPod connector in the speaker dock.
3. Connect the iPod to the iPod bracket on the speaker dock.

After the iPod is connected to the speaker dock, the unit will charge the iPod.

Using your speaker dock

To play your iPod on your speaker dock:

1. Connect your iPod to the speaker dock (see "Docking an iPod with your speaker dock" in your *User Guide*.)
2. Press ⏻ **POWER/** ►II, to turn on the speaker dock.
3. Press ⏻ **POWER/** ►II again to begin playing your iPod.
4. Make the following adjustments, according to your preference:
   - Press **VOLUME +** or **-** to adjust the volume.
   - Press **EQ** to cycle through the available sound preset modes. Choices include **ROCK**, **CLASSIC**, **JAZZ**, or **POP**.
   - Press **MUTE** to mute the sound. Press again to restore the sound to the previous setting.
5. You can also select the music you want to listen to by doing the following:
   - Press **NEXT/+** ►►I or **PREV/-** I◄◄ to skip tracks forward or back, or press and hold **NEXT/+** ►►I or **PREV/-** I◄◄ to search through individual tracks.
   - Press **CHAPTER**, **ALBUM**, or **PLAYLIST** to navigate through the chapters, albums, or playlists on the docked iPod.
   - Press **MENU** ▲ or **MENU** ▼, then **SELECT** to navigate the iPod's menu and make selections.
   - Press **SHUFFLE** to turn on the shuffle option.
   - Press **REPEAT** once to repeat the current track, or twice to repeat the entire album or playlist.
6. To turn the speaker dock off, press ⏻ **POWER/** ►II.

For more information about using your speaker system, including connecting it to a stereo system, see your *User Guide*.

One-year limited warranty

See the *User Guide* or visit www.insigniaproducts.com for details.

© 2009 Best Buy Enterprise Services, Inc. All rights reserved.